

# Laser Induced Deformation and Breakup of Acoustically Levitated Droplet

Anil Yadav (210137)

Department of Aerospace Engineering, IIT Kanpur  
Supervisor: Dr. D Chaitanya Rao

April 16, 2025

# Introduction: Importance & Motivation

- **Laser-induced droplet breakup** refers to the disintegration of liquid droplets upon exposure to focused laser energy, enabling controlled manipulation of microscale fluids without physical contact.
- This phenomenon is crucial for applications in nanolithography and semiconductor cleaning , offering precise control over droplet dynamics and breakup behavior.

## Focus of This Study:

- Investigating response of levitated droplets (Decane, Ethanol, Xylene) to CW CO<sub>2</sub> laser.
- Explore thermally driven deformation and breakup .

## Motivation:

- CW laser-induced breakup is less explored.

# Project Objectives

- Investigate deformation and breakup of levitated droplets under CW  $\text{CO}_2$  laser.
- Compare responses of different liquids with varying properties.
- Examine influence of laser power on breakup.
- Identify conditions leading from deformation to fragmentation.

# Background: Key Concepts

## **Droplet Physics:**

- Surface Tension, Viscosity, Internal Pressure, Boiling Point.

## **Laser Interaction (CW CO<sub>2</sub> Laser):**

- Localized energy absorption.
- Gradual heating, vaporization, pressure buildup, instability.

## **Acoustic Levitation:**

- Contactless droplet suspension using ultrasonic waves.

# Experimental Setup: Overview

- **Laser:** CW CO<sub>2</sub> (10W, 10.6  $\mu\text{m}$ )
- **Beam Expander & Lens:** 5x, ZnSe lens ( $f=50.8$  mm)
- **Levigator:** Tech5 AG, 100 kHz
- **Camera:** Photron NOVA S6
- **Illumination:** Diffused light source
- **Sync System:** Synchronizes laser, illumination, camera




Figure: Schematic of the experimental setup

# Experimental Setup: Laser & Focusing

- **Laser:** CW CO<sub>2</sub> (10 W,  $\lambda = 10.6 \mu\text{m}$ )
- **Beam Diameter:** Initial = 3.5 mm, Expanded = 17.5 mm
- **Lens:** ZnSe,  $f = 50.8 \text{ mm}$
- **Spot Size:**  $47 \mu\text{m}$

**Significance:** Spot size much smaller than droplet ( $350 \mu\text{m}$ ) → Localized heating

# Experimental Setup: Levitation & Droplet

- **Levigator:** Tech5 AG, 100 kHz ultrasonic
- **Droplet:** 350  $\mu\text{m}$  size, suspended at pressure antinode
- **Environment:** Room temperature, ambient air




Figure: Levitator diagram

# Experimental Setup: Imaging & Synchronization

- **Camera:** Photron NOVA S6, 50,000 fps, 384x256 px
- **Lighting:** Backlight with diffuser
- **Calibration:** Scale = 0.013095 mm/pixel
- **Sync:** Triggered start for camera, laser, light



# Investigated Liquids & Properties

**Liquids Studied:** Ethanol, n-Decane, Xylene

<b>Property</b>	<b>Ethanol</b>	<b>n-Decane</b>	<b>Xylene</b>
Boiling Point (°C)	78	174	140
Viscosity (mPa·s)	1.2	0.92	0.65
Surface Tension (mN/m)	22	24	28

**Table:** Properties of the studied liquids

# Observations: Ethanol Droplet

- Rapid heating and deformation
- Fine mist / minute droplets (vapor-like outflow).
- Rapid surface vaporization due to low boiling point ( $78^{\circ}\text{C}$ ) and potentially lower/surface IR absorption hence Less internal pressure buildup.




Figure: Ethanol droplet breakup at 80% laser power .

# Observations: Decane Droplet

- Subtle ruptures initiated near the rear side
- Lower viscosity and surface tension contribute to early instability despite high boiling point (174°C). Moderate IR absorption may allow localized internal heating/rupture
- Asymmetric expansion/perturbations cause the droplet out of focus.





Figure: Decane droplet breakup at 80% laser power.

# Observations: Xylene Droplet

- intense and delayed breakup
- Abrupt initial burst → Bag-like sheet formation → Disintegration
- Stronger IR absorption and higher boiling point (  $140^{\circ}\text{C}$  ) lead to significant energy accumulation and internal pressure buildup before explosive rupture



**Figure:** Breakup of xylene droplet at 80% laser power.

# Observations: Xylene Droplet

- Droplet flattens and expands outward (liquid sheet).
- Mass accumulation at sheet edges → Thickening.
- Destabilization → Ligament formation & disintegration.




Figure: Breakup of xylene droplet at 40% laser power.

# Observations: Xylene Droplet

- Relatively mild and delayed breakup.
- Initial Rupture Time:  $\sim 30.4$  ms (Tiny surface burst observed).
- evolution of ligaments and then they breakup into secondary droplets




Figure: Breakup of xylene droplet at 20% laser power.

# Conclusion

- CW CO<sub>2</sub> laser-induced breakup of levitated Ethanol, Decane, and Xylene droplets was successfully investigated.
- Breakup dynamics depend strongly on laser power and fluid properties.
- Higher laser power leads to faster and more intense breakup.
- IR absorption, viscosity, surface tension, and boiling point govern droplet response.

# Future Work

- Investigation of different laser wavelengths or pulsed laser configurations.
- Quantitative analysis of fragment size distribution
- study related to ignition sustain by laser energy during breakup



# Acknowledgments

- Dr. D Chaitanya Rao for guidance
- Mr. Avadhesh Kumar Tiwari (Phd) for experimental setup (Atomization and Laser-fluid Lab)

# References



A. Marzo, A. Barnes, and B. W. Drinkwater, "TinyLev: A multi-emitter single-axis acoustic levitator," *Review of Scientific Instruments*, vol. 88, no. 8, 2017. Available: <https://pubs.aip.org/aip/rsi/article/88/8/085105/962938/TinyLev-A-multi-emitter-single-axis-acoustic>



Tec5USA, *Ultrasonic Levitator Manual*, [Online]. Available: <https://www.yumpu.com/en/document/read/10788669/ultrasonic-levitator-manual-tec5usa>



NIST Chemistry WebBook, *NIST Standard Reference Database* , Available: <https://doi.org/10.18434/T4D303>

Thank you!